GET TO KNOW YOUR REMOTE CONTROL

MICROPHONE for Voice Search.

POWER turns the TV on or off.

INPUT selects the input for your TV.

GUIDE takes you to the on-screen Gu

VOL controls the volume on your TV.

CH changes the channels up and down.

Takes you to the main menu.

"i" shows more information about what you're watching.

MUTE turns the sound on or off.

CONTROLLER navigates using the UP, DOWN, LEFT or RIGHT areas.

OK, in the center of the Controller, accepts the current selection.

DVR lets you schedule and access your recordings.

BACK opens the main menu or returns to the previous screen.

VOICE SEARCH finds your shows. On some remotes VOICE SEARCH looks like this.

LAST goes to the channel you last viewed.

APPS takes you to all your apps.

NETFLIX launches the Netflix app.

NUMBER BUTTONS enter numbers (e.g., channel numbers or Parental Controls PIN).