

The DVR is a small computer that allows for recording a show with no programming knowledge. This electronic recorder enables viewers to archive programs and watch them at their convenience. People become faster at using the DVR with practice and knowing how to access the device's options.

Basic DVR Remote Functions



◀◀ **REWIND**

Rewind recorded shows to the beginning or to a favorite spot.

▶ **PLAY**

Play your show from the beginning or pick up where you left off.

▶▶ **FAST FORWARD**

While watching recorded programs, fast-forward through commercials or to the place where you left off.

● **RECORD**

Select a program to record by using the record button and on-screen guide. Set a series recording or record by time using the Main Menu.

|| **PAUSE**

Pause live and recorded programs for any interruptions and return right where you left off.

■ **STOP**

Stop watching recorded programs and return to live TV.

GUIDE

Access to the TV guide with programming seven days in advance.

MENU

Quick access to Menu functions: DVR, On-Demand, Pay-Per-View, HD, Favorites, Search, Movies, Sports, Parental Lock.

BACK

Return to the last screen.



Your Hometown Entertainment Provider!

Fidelity DVR Instructions

Record Shows Different Ways.

1. Go to the channel you want to record, click the "Record" button on the remote control.
2. Use the on-screen guide to find the program you'd like to record. Highlight the program and hit the "Record" button. Follow the on-screen prompts to confirm recording.
3. Go to the Main Menu Search and put in the first four letters of a show's title to find it. Highlight the title and select the "Record" button.

Delete Shows.

Go to the DVR screen that lists recorded shows. Select a show. Click "Delete" from the Menu options.

Make A Series Recording.

Click the on-screen guide button on the remote control. Go to the show to be recorded. Click the "OK" button. Select "Create a Series Recording" from Record Menu.

Use Real-Time Functions.

Hit the double arrows to reverse parts of a live TV program that is still recording. Click the double line to pause a show and the square button to stop playing a show. The show remains on the DVR. These functions allow you to enjoy TV around your schedule.

Recording Tips & Warnings



The series recording menu allows you to record first-run episodes, repeated shows or all episodes of a show.



Be aware of space limitations on the DVR. As space gets low, older shows will get "bumped" for newer ones or an error message will pop up reminding you that you are running low on space. Delete the unwanted shows periodically.

IMPORTANT SAFETY INSTRUCTIONS

YOUR DVR BOX IS AN ADVANCED INTERACTIVE DIGITAL CABLE RECEIVER. THE DVR SET-TOP BOX HAS AN INTERNAL HARD DISK DRIVE. TO HELP REDUCE THE POTENTIAL FOR DAMAGE, IT MUST BE HANDLED IN MUCH THE SAME WAY AS A COMPUTER. THE DVR HAS BEEN DESIGNED TO OPERATE RELIABLY IN A WELL-VENTILATED HOUSEHOLD ENVIRONMENT.

Position the DVR in an open space that allows airflow around the unit (there should be at least 2 inches of space above and on all sides).

Slots and openings in the unit cabinet are provided for ventilation. Do not block the slots and openings in the DVR or place anything on top of the DVR. Also, you should place the DVR on a hard surface with adequate support.

Ensure the DVR is not near any external heat source that could raise the temperature around the unit.

To prevent fire or shock hazard, do not expose this appliance to rain or moisture. Unplug the unit from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning. Fidelity recommends that you use a surge protector to power your digital converter box.



Cable Television Repair Services

Toll-Free - 1-866-828-1611

Monday-Friday: 8:00 a.m. to 10:00 p.m.

Saturday: 8:00 a.m. to 5:00 p.m.

Thank You For Choosing Fidelity!